

DANNER

MANUFACTURING, INC.

COVER CARE™ 300


CLOG RESISTANT POOL COVER PUMP
ITEM # 02540

SUPREME-HYDROPONICS®

UTILITY PUMP
ITEM # 40460

PARTS LIST

DESCRIPTION	PART NO.
Prefilter	21505
Impeller	21555



WARNING - Risk of electric shock. This pump should not be used to drain the pool cover if there are people in the pool.

WARNING - Risk of electric shock. Connect only to a grounding type receptacle protected by a Class A ground-fault circuit-interrupter.

Keep these instructions for future reference.

CARE AND OPERATING INSTRUCTIONS FOR COVER-CARE™ & SUPREME-HYDROPONICS® MODEL 300 PUMP FEATURES

This pump is a magnetically driven centrifugal water pump. It has no seals to wear and contains no oil. The pump has a garden hose head on the pump outlet. A garden hose can be used to direct the water away from the pool. Place the pump where the water is the deepest. Bear in mind that the pump cannot pull water up from a lower level unless submerged and filled with water when starting. Should the pump not start pumping, disconnect electric, wiggle hose a few times and try again. All electrical components are encapsulated in epoxy with no seals to wear or break. The energy used is approximately 1/2 of regular motor driven pumps. The prefilter is provided for use in situations where deposits in the water could clog or damage the pump. This helps give uninterrupted service.

PREFILTER

A prefilter is supplied. The primary purpose is to prevent blockage of the pump by leaves etc. The prefilter may need occasional cleaning and eventual replacement. Do not use pump without prefilter to prevent blockage and impeller damage.

SERVICE AND MAINTENANCE

The housing should occasionally be removed to clean and inspect the impeller assembly. The impeller is the only serviceable item and can be pulled out of the body. Do not take the impeller apart. If it is worn or broken the entire impeller should be replaced. This will restore the pump to original capacity. Pumps taken out of service for an extended period with fluid inside run the risk of forming a crust which may prevent subsequent starting. Always check cord for sharp bends which can cause premature cracking. Do not use power cord to lift or move pump.

ELECTRICAL PRECAUTIONS

Always use a properly grounded outlet. Do not immerse plug in water. **DO NOT REACH INTO WATER TO REMOVE PLUG. TURN OFF CIRCUIT FIRST.** A Drip Loop should be provided. The Drip Loop is a loop in the cord below the level of the receptacle or plug that prevents water from traveling along the cord. The National Electric Code requires that a ground fault circuit interrupter (GFCI) be installed in the branch circuit supplying fountain or pond equipment. Your dealer can supply GFCI units. **NEVER REMOVE GROUND PIN FROM PLUG.** **WARNING: FOR YOUR PROTECTION ALWAYS UNPLUG THE UNIT FROM ITS POWER SOURCE BEFORE INSTALLING OR SERVICING. SHOULD THE UNIT APPEAR TO NOT BE WORKING DO NOT REACH, REMOVE OR DISASSEMBLE UNIT BEFORE YOU DISCONNECT POWER.** The pump is intended to pump water only. It cannot be used to pump oils, solvents or gasoline.

LIMITED WARRANTY

E.G. Danner Mfg. Inc will repair or replace any pump found to be defective within one year of original purchase. This warranty does not cover the replaceable filtering material supplied with the pump as it is considered expendable. Cutting or altering cord voids any warranty consideration. For warranty repair return only the part that is defective to our factory. Please include a dated proof of purchase and \$5.00 for postage and handling. Damages or injuries resulting from negligence or misuse of the product are not covered by warranty. This warranty gives you specific legal rights. You may have other rights which vary from state to state.