size:80*130mm

Jacuzzi®

# MANUAL VAC
Quick Guide for removing debris

 1. Rotate end-cap assembly counterclockwise.

 2. Gently pull end-cap assembly out.

End-Cap Base
End-Cap Assembly

 3. Hold the end-cap assembly and rotate filter screen counterclockwise about 1/8" or until you feel it stop.

 4. Pull off filter screen and rinse out the debris from both filter screen and end-cap assembly. Make sure seal ring inside end-cap assembly is flat with no grit.

 5. Line up the filter screen notches with end-cap assembly grooves. Slide filter screen into place by gently rotating clockwise 1/8" or until filter screen locks into place.

 6. Rotate end-cap assembly back into body and lock tight.

 WIDE-END NOZZLE

 WALL MOUNT

 SLIDE-ON BRUSH

 DUAL-END NOZZLE

8 18775 01075 5

SKU48827

Jacuzzi®

www.jacuzzipool.com