

QUICK START GUIDE

CROSS WIND V™ + Raymote™


1 Sign-Up with the Raymote App




Available for:



Sign-up



Create an account




Create a password from email

If you do not receive the invitation email, check your Junk folder.


2 Turn on the Heater




3 On your phone, click add new device



4 Stand close to the heater to connect to the Raymote app



iOS View




Android View



The **CONNECT** key displays the ID and connectivity status.

5 Select your Wi-Fi network and enter your password


Make sure to have a strong Wi-Fi signal near the heater.






6 The heater is connecting to your Wi-Fi



7 Name your heater to complete the setup and enjoy Raymote control



You can invite family members and service suppliers to your Raymote organization

-  Control and schedule your pool heater
-  Automates heat up time by learning pool size
-  Raymote mobile app – allows on-the-go control of your pool temperature and so much more

Having trouble connecting your heater?



Try these suggestions to improve your Wi-Fi signal:

- Confirm that your Wi-Fi signal strength is strong enough to reach the heater (walls and fences may affect Wi-Fi signal)
- Reduce distance between Wi-Fi router and the heater
- Add a Wi-Fi range extender
- Enable a new Wi-Fi access point

For more support visit: www.raypak.com/raymote

Scan Here

www.Raypak.com

2151 Eastman Avenue | Oxnard, CA 93030 | 805-278-5300

Litho in U.S.A. ©2023 Raypak, Inc. P/N 100-10000818 Rev 00 Effective 03-27-23 Replaces NEW