



Gecko XP2e Spa Pump Cross Reference List

Utilize CTRL+F on your keyboard to locate your original pump.

If your pump is not listed please call a PoolSupplyWorld account manager at **800-772-0467**.

*When referring to your old pump model number, the last 3 digits after the dash can be disregarded.

**Comments indicate slight differences between original and new pump. Save your existing cord.

Old Part #*	New Pump Sku #	Change Comments**
05015001-2040	06115517-2040	xp2, 2spd
05015002-5040	n/a	
05015003-5340	n/a	no cord
05015005-1000	06115517-2040	xp2, 2spd
05015081-2300	06115517-2040	no cord, 2 speed, xp2
05015081-2340	06115517-2040	no cord, 2 speed, xp2
05015500-2000	06115000-1040	no cord, xp2, 2spd
05015558-1340	06115517-2040	xp2, no cord, 2spd
05015684-2300	06115517-2040	no cord, 2 speed, xp2
05015959-1340	06115517-2040	no cord, 2 speed, xp2, will have to move to R6
05015964-1301	06115517-2040	no cord, 2 speed, xp2, will have to move to R3
05015964-1340	06115517-2040	no cord, 2 speed, xp2, will have to move to R3
05020400-2040	06120500-2040	no cord, xp2, 2 speed motor
05020737-2000	06120500-2040	xp2, 2 speed motor
05025737-2000	06125000-1040	xp2, 2 speed motor
05030000-2340	06130395-2040	no cord, xp2, 2spd
05115001-2300	06115517-2040	no cord, xp2
05115001-2340	06115517-2040	no cord, xp2
05115002-2300	06115000-1040	no cord, xp2
05115003-2340	06115517-2040	no cord, speed reverse, xp2
05115004-2000	06115000-1040	xp2, will have to move to R9
05115004-2300	06115000-1040	xp2, will have to move to R9
05115005-2040	06115000-1040	no cord, xp2
05115005-2340	06115000-1040	no cord, xp2
05115006-2300	06115517-2040	no cord, xp2
05115006-2340	06115517-2040	no cord, xp2
05115007-2340	06115000-1040	no cord, xp2
05115008-2340	06115000-1040	no cord, xp2
05115008-5340	06115000-1040	no cord, xp2
05115009-2340	06115000-1040	xp2
05115459-2040	06115517-2040	no cord, xp2
05115459-2300	06115517-2040	no cord, xp2
05115761-2000	06115517-2040	xp2
05115761-2040	06115517-2040	xp2
05115792-2370	06115517-2040	no cord, xp2

05115894-2300	06115517-2040	no cord, xp2
05120000-2040	06120500-2040	no cord, xp2
05120000-2300	06120500-2040	no cord, xp2
05120001-2040	06120500-2040	no cord, xp2
05120001-2340	06120500-2040	no cord, xp2
05120002-2300	06120500-2040	no cord, xp2
05120608-2300	06120500-2040	no cord, xp2
05120761-2000	06120500-2040	xp2
05120761-2040	06120500-2040	xp2
05125000-2340	06120500-2040	no cord, xp2
05125001-2040	06125000-1040	no cord, xp2
05125001-2340	06125000-1040	no cord, xp2
05125002-2340	06125000-1040	no cord, xp2
05125761-2000	06125000-1040	xp2
05125761-2040	06125000-1040	xp2
05215000-7340	06115000-1040	no cord, replacement will be 48fr
05215001-7340	06115517-2040	no cord, replacement will be 48fr
05215500-2000	56fr in 115v n/a	xp2 48fr : could use 1.5HP, 115v
05215737-2000	Use 2HP, 05320761-2	or could use xp2 48FR 2spd, 1,5Hp
05220001-2040	05320761-2000	no cord, 2spd
05220001-2340	05320761-2000	no cord, 2spd
05220002-2040	05320761-2000	no cord, 2spd
05220002-2340	05320761-2000	no cord, 2spd
05220400-7040	05320761-2000	no cord, 2spd
05220737-2000	05320761-2000	no cord, 2spd
05225000-7300	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp), regular motor with cap.
05225427-2300	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05225427-7300	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9, regular motor with cap.
05225428-2300	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05225428-7300	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3, regular motor with cap.
05225737-2000	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp)
05225980-2300	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp)
05230366-2300	05334012-2040	no cord, 2speed motor
05234001-2300	05334012-2040	no cord, 2speed motor
05234002-2340	05334012-2040	no cord, 2speed motor
05234002-7040	05334012-2040	no cord, 2speed motor
05242000-2340	05340009-5040	no cord, will be 2 speed motor
05242001-2340	05340009-5040	no cord, will be 2 speed motor
05242002-2040	05340009-5040	no cord, will be 2 speed motor
05242002-2340	05340009-5040	no cord, will be 2 speed motor
05242003-2340	05340009-5040	no cord, will be 2 speed motor
05242003-2370	05340009-5040	no cord, will be 2 speed motor
05242004-2300	05340009-5040	will be 2 speed motor
05242372-2340	05340009-5040	no cord, will be 2 speed motor
05242372-2370	05340009-5040	no cord, will be 2 speed motor

05242376-2370	05340009-5040	no cord, will be 2 speed motor
05315000-7340	Use 2HP, 05320761-2	no cord(could use xp2, 48frame, 1.5HP)
05315001-7370	Use 2HP, 05320761-2	no cord(or could use xp2 48FR 2spd, 1,5Hp)mtr with cap
05315761-2000	Use 2HP, 05320761-2	no cord (or could use xp2 48FR 2spd, 1,5Hp)
05315761-2040	Use 2HP, 05320761-2	no cord (or could use xp2 48FR 2spd, 1,5Hp)
05320001-7340	05320761-2000	no cord, motor has a capacitor instead of relay now
05320003-2040	05320761-2000	no cord
05320003-2340	05320761-2000	no cord
05320004-2040	05320761-2000	no cord
05320004-2340	05320761-2000	no cord
05320005-1340	05320761-2000	no cord
05320008-2300	05320761-2000	no cord
05320008-2340	05320761-2000	no cord
05320008-7300	05320761-2000	no cord, motor has a capacitor instead of relay now
05320009-7340	05320761-2000	no cord
05320011-7040	05320761-2000	no cord, motor has a capacitor instead of relay now
05320306-1340	05320761-2000	
05320761-2000	05320761-2000	no cord
05325000-7340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05325001-2300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05325002-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05325003-2300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05325450-2340	n/a Use 2 or 3HP	(or could use xp2 48FR 2spd, 2,5Hp)
05325761-2000	n/a Use 2 or 3HP	(or could use xp2 48FR 2spd, 2,5Hp)
05325761-2300	n/a Use 2 or 3HP	(or could use xp2 48FR 2spd, 2,5Hp)
05330001-2300	05334012-2040	no cord
05330002-1300	05334012-2040	no cord
05330002-2040	05334012-2040	no cord
05330002-2300	05334012-2040	no cord
05330002-2340	05334012-2040	no cord
05330306-1340	05334012-2040	no cord
05330309-2300	05334012-2040	no cord
05330883-2300	05334012-2040	no cord
05334001-2300	05334012-2040	no cord
05334002-7300	05334012-2040	no cord
05334003-2300	05334012-2040	no cord
05334004-2340	05334012-2040	no cord
05334004-7040	05334012-2040	no cord
05334005-2340	05334012-2040	no cord
05334006-7040	05334012-2040	no cord
05334007-2300	05334012-2040	will have to move to R3
05334008-7300	05334012-2040	no cord, motor has a capacitor instead of relay now
05334009-2340	05334012-2040	no cord, will have to move to R3
05334010-1340	05334012-2040	no cord
05334011-2300	05334012-2040	no cord, will have to move to R3
05342000-2340	05340009-5040	no cord
05342001-2040	05340009-5040	no cord, speed reverse

05342001-2340	05340009-5040	no cord, speed reverse
05342002-2340	05340009-5040	no cord
05342003-2340	05340009-5040	no cord
05342003-2370	05340009-5040	no cord
05342004-2300	05340009-5040	
05342365-2340	05340009-5040	no cord
05342365-2370	05340009-5040	no cord
05342379-2370	05340009-5040	no cord
05342792-2340	05340009-5040	no cord
05515000-2300	06115517-2040	no cord, 2 speed, xp2
05515000-2340	06115517-2040	no cord, 2 speed, xp2
05515558-2340	06115517-2040	xp2, no cord, 2spd
05515661-1300	06115517-2040	no cord, 2 spd, xp2, will have to move to R3
05515684-2340	06115517-2040	no cord, 2 speed, xp2
05515880-1300	06115517-2040	no cord, 2 spd, xp2, will have to move to R3
05517000-2340	06115000-1040	no cord, xp2, 2spd
05520000-2300	06120500-2040	no cord, xp2, 2 spd, will have to move to R9
05520000-2340	06120500-2040	no cord, xp2, 2 spd, will have to move to R9
05520001-2340	06120500-2040	no cord, xp2, 2 speed motor
05520002-2340	06120500-2040	no cord, xp2, 2 speed motor
05520003-5340	06120500-2040	xp2, 2 speed motor
05520004-2300	06120500-2040	no cord, xp2, 2 speed motor
05520092-1340	06120500-2040	no cord
05525000-2340	06120500-2040	no cord, xp2, 2 spd, will have to move to R9
05525000-2370	06120500-2040	no cord, xp2, 2 spd, will have to move to R9
05525434-2340	06125000-1040	no cord, xp2, 2 speed motor
05525661-1300	06125000-1040	no cord, 2 spd, xp2, will have to move to R3
05525794-2340	06125000-1040	no cord, xp2, 2 spd, will have to move to R9
05525794-2370	06125000-1040	no cord, xp2, 2 spd, will have to move to R9
05615001-2300	06115517-2040	no cord, xp2
05615001-2340	06115517-2040	no cord, xp2
05615002-2340	06115517-2040	no cord, xp2
05615003-2000	06115000-1040	xp2
05615003-2300	06115000-1040	xp2
05615004-2340	06115000-1040	no cord, xp2
05615005-2340	06115000-1040	no cord, xp2
05615006-2340	06115517-2040	xp2
05615007-2300	06115000-1040	no cord, xp2
05615008-2340	06115000-1040	no cord, xp2
05615316-1300	06115000-1040	no cord, xp2, will have to move to R3
05615316-1340	06115000-1040	no cord, xp2, will have to move to R3
05615316-2300	06115000-1040	no cord, xp2, will have to move to R3
05615316-2340	06115000-1040	no cord, xp2, will have to move to R3
05615319-2040	06115000-1040	no cord, xp2
05615319-2300	06115000-1040	no cord, xp2
05615319-2340	06115000-1040	no cord, xp2
05615319-2381	06115000-1040	no cord, xp2

05615459-2300	06115517-2040	no cord, xp2
05617001-2300	06115000-1040	no cord, xp2
05617001-2340	06115000-1040	no cord, xp2
05617002-2300	06115000-1040	xp2
05617003-2300	06115000-1040	xp2, will have to move to R3
05617004-2300	06115000-1040	xp2, will have to move to R9
05617421-2340	06115000-1040	no cord, xp2
05618000-2340	06115517-2040	no cord, xp2
05620001-2300	06120500-2040	no cord, xp2, wil have to move toR9
05620001-2340	06120500-2040	no cord, xp2, wil have to move toR9
05620002-2040	06120500-2040	no cord, xp2
05620003-2040	06120500-2040	no cord, xp2, wil have to move toR9
05620003-2340	06120500-2040	no cord, xp2, wil have to move toR9
05620004-2000	06120500-2040	xp2
05620004-2300	06120500-2040	xp2
05620005-2340	06120500-2040	xp2
05620006-5340	06120500-2040	xp2
05620007-2300	06120500-2040	no cord, xp2
05620256-1340	06120500-2040	no cord, xp2
05620374-2340	06120500-2040	no cord, xp2
05620485-2340	06120500-2040	no cord, xp2
05620489-2340	06120500-2040	no cord, xp2
05625000-2040	06125000-1040	no cord, xp2, wil have to move toR3
05625001-2040	06125000-1040	no cord, xp2
05625002-2340	06125000-1040	no cord, xp2, wil have to move toR9
05625003-2070	06125000-1040	no cord, xp2, wil have to move toR9
05625003-2370	06125000-1040	no cord, xp2, wil have to move toR9
05625287-1300	06125000-1040	no cord, xp2, wil have to move toR3
05625356-2370	06125000-1040	no cord, xp2
05625357-2370	06125000-1040	no cord, xp2, wil have to move toR9
05625387-2070	06125000-1040	no cord, xp2, wil have to move toR9
05625387-2370	06125000-1040	no cord, xp2, wil have to move toR9
05625489-2340	06125000-1040	no cord, xp2
05625894-1300	06125000-1040	no cord, xp2
05634000-2340	06130395-2040	no cord, xp2, will have to move to R9
05720000-7340	05320761-2000	no cord, 2spd
05720001-1340	05320761-2000	no cord, 2spd
05720003-7340	05320761-2000	no cord, 2spd
05725001-2040	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05725002-2040	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05725002-2340	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05725003-2340	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05725004-2000	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp)
05725004-2300	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp)
05725004-2340	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp)

05725005-2340	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05725006-7340	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05725007-2361	n/a Use 2 or 3HP (2spd	(or could use xp2 48FR 2spd, 2,5Hp)
05725008-2370	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05725009-7370	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05725354-2340	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05725354-2370	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05725363-2370	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05725414-2370	n/a Use 2 or 3HP (2spd	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05725794-7040	05334012-2040	no cord, 2spd, will have to move to R9
05730000-2340	05334012-2040	no cord, 2 speed
05734000-2340	05334012-2040	no cord, 2speed motor
05734001-2361	05334012-2040	2 speed motor
05734002-2000	05334012-2040	no cord, 2speed motor
05734002-2300	05334012-2040	no cord, 2speed motor
05734003-7361	05334012-2040	2 speed motor, motor has a capacitor instead of relay now
05734004-5340	05334012-2040	2 speed motor
05734004-7340	05334012-2040	no cord, 2speed motor
05734005-7300	05334012-2040	no cord, 2speed motor
05740000-2361	05340009-5040	will be 2 speed motor
05742372-2340	05340009-5040	no cord, will be 2 speed motor
05815000-1040	Use 2HP, 05320761-2	no cord (or could use xp2 48FR 2spd, 1,5Hp)
05815000-1340	Use 2HP, 05320761-2	no cord (or could use xp2 48FR 2spd, 1,5Hp)
05815001-7340	Use 2HP, 05320761-2	no cord (or could use xp2 48FR 2spd, 1,5Hp) will have to move to R9
05815002-7340	Use 2HP, 05320761-2	no cord (or could use xp2 48FR 2spd, 1,5Hp)
05815003-7340	Use 2HP, 05320761-2	no cord(could use xp2, 48frame, 1.5HP) mtr with cap
05815004-1040	Use 2HP, 05320761-2	no cord(could use xp2, 48frame, 1.5HP)
05815510-2340	06115000-1040	no cord, xp2
05818000-7340	06115517-2040	no cord, mtr with cap, replacement will be 48fr
05820000-1340	05320761-2000	no cord
05820000-2340	05320761-2000	no cord
05820001-2300	05320761-2000	
05820002-2300	05320761-2000	no cord
05820003-2040	05320761-2000	no cord
05820003-2340	05320761-2000	no cord
05820004-7340	05320761-2000	no cord, will have to move to R9
05820005-7340	05320761-2000	no cord, motor has a capacitor instead of relay now
05820006-7340	05320761-2000	no cord, motor has a capacitor instead of relay now, will have to move to R9
05820007-1340	05320761-2000	no cord
05820397-7340	05320761-2000	no cord, motor has a capacitor instead of relay now
05820782-2340	05320761-2000	no cord, will have to move to R3
05825000-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)

05825001-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05825002-2040	n/a Use 2 or 3HP	no cord, speed reverse(or could use xp2 48FR 2spd, 2,5Hp)
05825002-2340	n/a Use 2 or 3HP	no cord, speed reverse(or could use xp2 48FR 2spd, 2,5Hp)
05825003-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825004-2000	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825004-2300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825004-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825004-2381	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825005-2040	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05825005-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05825006-2340	n/a Use 2 or 3HP	no cord, speed reverse(or could use xp2 48FR 2spd, 2,5Hp)
05825007-2000	n/a Use 2 or 3HP	(or could use xp2 48FR 2spd, 2,5Hp)
05825007-2300	n/a Use 2 or 3HP	(or could use xp2 48FR 2spd, 2,5Hp)
05825008-2300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825009-2300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825010-2361	n/a Use 2 or 3HP	(or could use xp2 48FR 2spd, 2,5Hp)
05825011-7300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825012-7340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05825014-7340	n/a Use 2 or 3HP	no cord(or could use xp2 48FR 2spd, 2,5Hp)mtr with cap
05825015-7300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3, mtr with cap
05825016-7370	n/a Use 2 or 3HP	no cord(or could use xp2 48FR 2spd, 2,5Hp)mtr with cap
05825017-7340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9, mtr with cap
05825018-7040	n/a Use 2 or 3HP	no cord(or could use xp2 48FR 2spd, 2,5Hp)mtr with cap
05825019-7300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3, mtr with cap
05825020-7370	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9, mtr with cap
05825021-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05825309-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825316-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R9
05825352-2370	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825352-7370	n/a Use 2 or 3HP	no cord(or could use xp2 48FR 2spd, 2,5Hp)mtr with cap
05825489-2040	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825489-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825489-5040	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp)
05825489-7340	n/a Use 2 or 3HP	no cord(or could use xp2 48FR 2spd, 2,5Hp)mtr with cap
05825685-2300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825778-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825892-2000	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3

05825892-2040	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825892-2060	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825892-2300	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825892-2340	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05825892-2360	n/a Use 2 or 3HP	no cord (or could use xp2 48FR 2spd, 2,5Hp) will have to move to R3
05830001-2300	05334012-2040	no cord
05830001-7300	05334012-2040	no cord, motor has a capacitor instead of relay now
05830002-1340	05334012-2040	no cord
05830002-2340	05334012-2040	no cord, speed inverted
05830003-2340	05334012-2040	no cord
05830703-2300	05334012-2040	
05834001-2040	05334012-2040	
05834001-2340	05334012-2040	
05834001-7040	05334012-2040	no cord, motor has a capacitor instead of relay now
05834002-2300	05334012-2040	no cord
05834002-2340	05334012-2040	no cord
05834003-2340	05334012-2040	no cord, will have to move to R9
05834004-1040	05334012-2040	no cord
05834004-1340	05334012-2040	no cord
05834005-2300	05334012-2040	no cord, will have to move to R9
05834005-2340	05334012-2040	no cord, will have to move to R9
05834006-2300	05334012-2040	no cord, will have to move to R3
05834006-2340	05334012-2040	no cord, will have to move to R3
05834007-2340	05334012-2040	no cord
05834008-2340	05334012-2040	
05834008-2361	05334012-2040	
05834008-7061	05334012-2040	no cord
05834009-2340	05334012-2040	no cord
05834010-2340	05334012-2040	no cord
05834011-2040	05334012-2040	no cord
05834011-2340	05334012-2040	no cord
05834012-7340	05334012-2040	no cord
05834013-7340	05334012-2040	no cord
05834014-7340	05334012-2040	no cord, motor has a capacitor instead of relay now, will have to move to R3
05834015-7340	05334012-2040	no cord, motor has a capacitor instead of relay now
05834016-7340	05334012-2040	no cord, motor has a capacitor instead of relay now, will have to move to R9
05834017-7340	05334012-2040	no cord
05834018-7300	05334012-2040	no cord
05834019-7300	05334012-2040	no cord
05834020-2300	05334012-2040	no cord
05834020-5300	05334012-2040	no cord
05834021-2300	05334012-2040	no cord

05834021-5300	05334012-2040	no cord
05834021-7300	05334012-2040	no cord, motor has a capacitor instead of relay now
05834022-2340	05334012-2040	no cord, will have to move to R3
05834023-2340	05334012-2040	no cord
05834024-7340	05334012-2040	no cord, motor has a capacitor instead of relay now
05834025-5040	05334012-2040	
05834025-5340	05334012-2040	
05840000-2361	05340009-5040	
05840375-2040	05340009-5040	no cord
05840375-2340	05340009-5040	no cord