



*Powered Solar Blanket Reel*

**Procedure for replacing or reprogramming a key fob remote:**

This procedure is done when a new key fob remote control is purchased for an existing system.

**Pool Boy® 1 and 2 (110 electric powered unit)**

- 1) Unplug the power supply unit from the GFI outlet for a minimum of 10 seconds.
- 2) Plug the power supply unit back in.
- 3) Within 5 seconds press and hold Both the “Extend” and “Retract” buttons simultaneously for 2 seconds.
- 4) Wait 2 seconds, your remote control system is now reprogrammed.

You can now operate the system as instructed in the operation manual.

**Pool Boy® 3 (Battery powered unit)**

- 1) Remove the cover from the drive side stand.
- 2) Locate the battery connector with the red and white wires that feeds the controller (which is mounted on the upper left side) from the battery. Unplug this connector.
- 3) Wait a minimum of 10 seconds then reconnect it.
- 4) Within 5 seconds press and hold both the “Extend” and “Retract” buttons for 2 seconds.
- 5) Wait 2 seconds, your remote control system is now reprogrammed.

You can now operate the system as instructed in the operation manual.

Customer Service: 574-266-1035 or [poolboyreels@gmail.com](mailto:poolboyreels@gmail.com)

5050 West Lake St. ♦ Chicago, IL 60644

♦ Phone: 574/266-1035 ♦