


1 Sign-Up with the Raymote App




Available for:



Sign-up



Create an account




Create a password from email

If you do not receive the invitation email, check your Junk folder.


2 Turn on the AVIA Heater



3 On your phone, click add new device



or



4 Stand close to the AVIA heater to connect to the Raymote app



iOS View




Android View




The CONNECT key displays the ID and connectivity status.

5 Select your Wi-Fi network and enter your password



Make sure to have a strong Wi-Fi signal near the heater.



6 The AVIA is connecting to your Wi-Fi



7 Name your heater to complete the setup and enjoy Raymote control



You can invite family members and service suppliers to your Raymote organization

- Control your entire pool system with AVIA
- Automates heat up time by learning pool size
- Raymote mobile app – allows on-the-go control of your pool temperature and so much more

Having trouble connecting your AVIA?



Scan Here

Try these suggestions to improve your Wi-Fi signal:

- Confirm that your Wi-Fi signal strength is strong enough to reach the heater (walls and fences may affect Wi-Fi signal)
- Reduce distance between Wi-Fi router and the heater
- Add a Wi-Fi range extender
- Enable a new Wi-Fi access point

For more support visit: www.raypak.com/raymote

www.raypak.com

2151 Eastman Avenue | Oxnard, CA 93030 | 805-278-5300

Litho in U.S.A. ©2022 Raypak, Inc. P/N 241945 Rev 4 Effective 04-15-22 Replaces 241945 Rev. 3