



TO SET PROGRAM

1. Pull **UP** trippers on dial to set desired **ON** times.
2. Turn dial clockwise until the time of day is adjacent to **TIME** arrow.

IN CASE OF POWER FAILURE RESET TIMER.

INTERMATIC INCORPORATED
 SPRING GROVE, ILLINOIS 60081 - 9698

MODEL NO:

**CLOCK MOTOR
 VOLTAGE:**

154SB8298

MADE AND PRINTED IN U.S.A.